



JOIN NO. ON PCB	1	2	4	5	6	7	8
WIRING TO:	MOTOR	REVERSE LIGHT	POWER LEFT	MOTOR	FORWARD LIGHT	LIGHT COMMON	POWER LIGHT
WIRE COLOR	ORANGE	YELLOW	BLACK	GREY	WHITE	BLUE	RED

DIAGRAM A

Correct placement of connceter:
Connector (White surface) face upware

Decoder installation:
1.Remove the tender body from the tender chassis by unscrew which under neath the tender chassis.
2.Connect the wires directly to the decoder wires,Match the color of wires according the diagram 'A' &sketch 'A' and sketch 'B'

