



JOIN NO. ON PCB	3	8	1	2	4	5	6	7
WIRING TO:	Aux1	POWER RIGHT	MOTOR	REVERSE LIGHT	POWER LEFT	MOTOR	FORWARD LIGHT	LIGHT COMMON
WIRE COLOR	GREEN	RED	ORANGE	YELLOW	BLACK	GREY	WHITE	BLUE

DIAGRAM A

Very important !!

Locomotive to tender connector. Proper placement, (white surface must face upward of connector)

Decoder installation :

- Carefully remove the tender body by carefully removing the screws from the bottom of the tender frame.
- Connect the wires directly to the existing decoder wires, match the color of the wires according to the diagram above diagram A and diagram B