

## SALOON AND BARBER SHOP

### LIST OF PARTS:

2 front walls (upper & lower)	1 chimney (2 pc.)	2 solid doors; 1 door with windows
1 rear wall	1 roof	2 saloon doors
1 left side wall	1 sign board	3 railings
2 right side walls (upper & lower)	2 lamps	2 figures (shown painted for illustrative purposes only)
1 balcony	1 set stairs - large	1 barber pole
1 sticker sheet	1 set stairs - small	1 smokestack
1 front walk	13 open windows (small)	1 cellar door
4 uprights	7 closed windows (large)	1 floor

### BEFORE STARTING:

- Check parts against list above.
- Carefully trim any excess plastic from the parts before assembling.
- You may wish to add a few drops of styrene cement to joints for permanent construction.

### ASSEMBLY INSTRUCTIONS: (use photos as a guide)

- With large tab at top, place window tab into opening from outside of wall first, and then snap window in place. Repeat for all windows. Note two types of windows.
- From inside walls, line up doors with hinge pins at top and bottom (1) (making sure the finished side faces outward and windows are toward top of door), drop door down so it hangs by hinges (2), and then gently snap under center tab (3 and 4). See photos 1, 2, 3, and 4 on reverse side. Note that the door with windows fits into right side doorway and solid doors fit into left side and barbershop doorways.
- Press (2) lamps into holes next to saloon doorway. From the outside, snap saloon doors into grooves provided.
- Press adhesive signs onto balcony sign board and over barber shop; press striped sticker around barber pole.
- Press lower walls together matching A to A, B to B, C to C and D to D (walls marked inside ends), and also insert bottom of wall corners into the floor. Corner pins in floor must fit into correct corresponding holes in bottom of walls. See photo on reverse side.
- Press woman's figure and sign board into holes in balcony. Press railings into row of inner-most holes in balcony, making sure round knobs on railings are on top.
- Slide balcony securely into place in front of building.
- Push (4) uprights, barber pole, and male figure into holes in front walk and then press front walk onto lugs on front wall and insert tops of uprights into upper balcony.
- Press large and small stairs, cellar door, and smokestack into holes provided.
- Assemble 2-piece chimney, insert into roof, and then press roof into place.



