


Please use a small pliers to adjust an angle of the support to hold the slide in horizontal position.



N Acela HHP-8 Instruction :

- 1) To open the body shell
 - a) Remove the body shell by gently pulling the bottom sides out and lifting the shell (see diagram B).
- 2) To operate from track/pantographs power (see diagram A and B)
 - Gently remove the roof vent cover (see diagram B) ,
 - a) To operate from track power , set the switch to " TRACK " (default) .
 - b) To operate from pantographs power , set the switch to " ANT " .
- 3) For digital command control (D.C.C) (optional) , see diagram A and B .
 - a) Remove the body shell OR remove the roof vent cover ,




Diagram A

