


DC MODE INSTRUCTIONS

(Separate power sources required for both track and turntable operation)



Speed controller for turntable sold separately (#44212)