




WOOD LOAD




COAL LOAD



OIL TANK



COAL LOAD ASSEMBLY



TENDER ASSEMBLY

For dummy plug installation:

- Remove the decoder;
- Install the dummy plugs by tool

CORRECT PLACEMENT OF DUMMY PLUG

Main PC Board

